

# Elite CSW200UL / SL3000UL / SL3000UL Dual GateCrafters Timer

1. **Switch Left Terminal** of timer to **Terminal 5** under Exit Loop of gate opener
2. **Switch Right Terminal** of timer to **Terminal 6** under Exit Loop of gate opener
3. **Terminal 1** of timer to **Transformer +** terminal (12VDC 500mA or Higher, not included)
4. **Terminal 2** of timer to **Transformer -** terminal (12VDC 500mA or Higher, not included)

